# bentgo° kidssnack

User's Manual



Thank you for purchasing Bentgo Kids Snack! Bentgo Kids Snack is the safe and leak-proof snack container designed for children ages 3 and older. With 2 different compartments, each perfectly sized for snacking, this lightweight and portable snack box encourages healthy, balanced eating.

#### **Features**

- Leak-proof design
- Drop-resistant durability
- Dishwasher, microwave & freezer-safe (we recommend hand washing outer shell to preserve leak-proof seal)
- Food-grade safe and eco-friendly materials
- No BPA, PVC, phthalates, lead, or vinyl

## **Using Your Bentgo Kids Snack**

- 1. Lift the latch on the front of Bentgo Kids Snack to open.
- 2. Fill compartment tray with your child's favorite snacks.
- 3. Close the lid and secure the latch.
- 4. Give to your child for an on-the-go snack Yes, it's that easy!

## Removing the Tray

We have designed the compartment tray with a notch in the front to keep the tray from lifting when the lid is opened.

- To insert the tray, slightly angle the front down and insert it into the outside shell first (see image below). The notch will line up with its counterpart in the shell. Once done, simply push the back of the tray down into the shell.
- Do the opposite to remove the tray push the back of the tray up first and then slide out.

### Special Use & Care Instructions

- · Wash before initial use.
- Removable tray is top-shelf dishwasher safe.
- Hand wash the outer shell to maintain the leak-proof seal on the silicone lining and to prevent damage to the latch and locking clip. Thoroughly dry.

#### Warnings

- Microwaving the tray is for reheating only Do not microwave for more than 3 minutes.
- To ensure mess-free opening and closing of your Bentgo Kids, do not overfill compartments.

## **Product Warranty**

Bentgo offers an industry-leading 2 Year Warranty. If you have warranty or product questions, please contact us directly at:

Email: support@bentgo.com
Phone: (657) 275-3738

(Available Monday-Friday, 8am-5pm PST)

### **Specifications**

Container Dimensions	6.1" x 4.2" x 2"
Tray Capacity	Large Compartment: 1 cup Small Compartment: ½ cup
Product Weight	9 oz.
Temperature Threshold	0° to 180° F

#### Materials\*

Outside Shell	ABS Plastic
Removable Tray	PP Plastic
Latches and Hinges	ABS Plastic

<sup>\*</sup>All materials are food-grade safe and eco-friendly



REV: 09.11.21