

User's Manual



Thank you for purchasing Bentgo Fresh! We designed this durable, leak-proof lunch solution to give users of all ages the same stylish design customers love about Bentgo Kids, but with a compartment tray that is portioned for larger appetites.

Features

- Leak-proof compartment tray prevents messy spills
- Removable divider fits in the largest compartment to create an additional 4th compartment*
- Dishwasher, microwave & freezer-safe (we recommend hand washing outer shell to preserve leak-proof seal)
- Food-grade safe and eco-friendly materials
- No BPA, PVC, phthalates, lead, or vinyl *Removable divider is only ideal for keeping dry foods separated. It will not prevent foods with juices from seeping through divider.

Using Your Bentgo Fresh

- Lift latches on the front of Bentgo Fresh to open.
- Add the removable divider if you need a 4th compartment. Fill each compartment with your desired entrée and sides.
- 3. Close the lid and secure the latches.

Removing the Tray

The compartment tray is designed with two notches on the front to keep it from moving around or lifting up when the top is opened.

- To insert the tray, slightly angle the front down and insert it into the outer shell first (see Arrow 1). The notches on the tray should line up with the notches inside the shell.
- Next, push the back of the tray down into the shell (see Arrow 2).
- To remove the tray, do the opposite. Push the back of the tray up first and then lift out.
- To add the removable divider, align the slots on the side of the divider with the tabs inside the largest compartment and push down. To remove the divider, pull it up (see Arrow 3).



Special Use & Care Instructions

- Wash before initial use.
- Removable tray is top-shelf dishwasher safe.
- Hand wash the outer shell to maintain the leak-proof seal on the silicone lining and to prevent damage to the latches and locking clips. Thoroughly dry.

Warnings

- Microwaving the tray is for reheating only Do not microwave for more than 3 minutes.
- To ensure mess-free opening and closing of your Bentgo Fresh, do not overfill any of the compartments.

Product Warranty

Bentgo offers an industry-leading 2 Year Warranty. If you have warranty or product questions, please contact us directly at: Email: support@bentgo.com

Phone: (657) 275-3738 (Available Monday-Friday, 8am-5pm PST)

Specifications

Container Dimensions	9.2" x 7" x 2.4"
Tray Capacity	Large Compartment: 3.3 cup Smaller Compartment A: 1 cup Smaller Compartment B: 1/3 cup
Temperature Threshold	0° to 180° F

Materials*

Outside Shell	ABS Plastic
Rubberized Overlay	TPE Thermoplastic Rubber
Removable Tray	PP Plastic
Latches and Hinges	ABS Plastic

*All materials are food-grade safe and eco-friendly

Santa Ana, CA 92704 bentgo.com REV: 05-2021