



Button Operation

- 1 Power ON/OFF
- 2 Increase Volume
- 3 Decrease Volume
- 4 Remix Adjust
- 5 Press: Play/Pause
- 6 Press: skips to previous song
- 7 Press: Skips to next song
- 8 Press: Skips to next song
- 9 Record
- 10 Charging Port
- 11 TF Card
- 12 AUX Out
- 13 USB Port

KARAOKE Mode

1. Hold the power button to turn the device on
2. Connect to the device via your Bluetooth Settings
3. Adjust the mic volume and reverb using the sliders on the device
4. Start playing!